USE THE 50, 75 OR 200 GPM TESTER TO SIMULATE ACTUAL OPERATING CONDITIONS OF THE SYSTEM UNDER TEST

Testing the pump: Operator runs engine at a specific rpm and adjusts tester's pressure compensating valve to simulate a work load. By comparing meter readings with manufacturer specs, proper operation of pump can be confirmed. If oil flow and pressure do not meet specs, the pump is faulty. Or, if test results and specifications agree, the operator will know that the problem is elsewhere in the system and that other tests must be performed. Regardless of the component being tested, hook-up and testing is accomplished in minutes. NOTE: These hydraulic testers should always be used with the owner's manual/manufacturers' specifications for the system under test.

MEASUREMENTS/ SPECIFICATIONS

Conversion Formulas

Cyl. Caps furnished with "C" Series Cylinders:

 5 ton cylinders
 No. 201375

 10 ton cylinders
 No. 201362

 15 ton cylinders
 No. 201362

 25 ton cylinders
 No. 201412

 55 ton cylinders
 No. 36161

 100 ton cylinders
 No. 36161


 100 ton cylinders
 No. 36161

PERFORMANCE

The table at right gives you an idea of what to expect when coupling RD series cylinders to a Power Team pump. Actual performance will vary according to job conditions.

Pump	Cylinder	Time to Extend Cylinder 1"			
Гишр	Cymnaci	100 psi	10,000 psi		
	RD55	1.0 sec.	12.0 sec.		
PE55	RD100	1.8 sec.	22.5 sec.		
	RD200	3.5 sec.	45.0 sec.		
	RD400	7.2 sec.	85.0 sec.		
	RD200	3.4 sec.	20.6 sec.		
PQ120	RD300	4.9 sec.	30.0 sec.		
Series	RD400	6.4 sec.	39.0 sec.		
	RD500	8.1 sec.	49.5 sec.		
PE400	RD300	3.0 sec.	8.5 sec.		
Series	RD400	3.9 sec.	11.1 sec.		
	RD500	4.9 sec.	14.1 sec.		

NOTE: Base mounting holes are standard on all RD cylinders. Orientation of base mounting holes to coupler. Orientation on RD300, RD400 & RD500 series is random.



BASE MOUNTING HOLES FOR "RD" CYLINDERS

Tonnage	10	25	55	80	100	150	200	300	400	500
No. of Holes	2	4	4	4	4	4	4	4	4	6
Thread Size	3/8"-16	¹ / ₂ "-13	5/8"-11	5/8"-11	3/4"-10	1"-8	11/4"-7	1 ¹ / ₄ "-7	11/2"-12	1 ³ / ₈ "-12
Depth	5/8"	3/4"	7/8"	7/8"	1"	1"	11/4"	1 ³ / ₄ "	17/8"	2"
B.C. Dia.	2"	23/4"	31/2"	41/2"	5 ¹ / ₂ "	6"	61/2"	6 ¹ / ₄ "	71/4"	8"
Orientation	Consult	the factor	у.		Ž		0 .			

MOUNTING HOLES FOR "RLS" CYLINDERS


RLS50	$^{11}/_{32}$ " C'bore x $^{1}/_{4}$ " deep, $^{7}/_{32}$ " thru hole
RLS100	²⁷ / ₆₄ " C'bore x ¹¹ / ₃₂ " deep, ⁹ / ₃₂ " thru hole


RLS200	³⁹ / ₆₄ " C'bore x ¹³ / ₃₂ " deep, ¹³ / ₃₂ " thru hole
RLS300	$^{39}/_{64}$ " C'bore x $^{7}/_{16}$ " deep, $^{13}/_{32}$ " thru hole

RLS500S	$^{45}/_{64}$ " C'bore x $^{1}/_{2}$ " deep, $^{15}/_{32}$ " thru hole
RLS750S	⁵¹ / ₆₄ " C'bore x ⁹ / ₁₆ " deep, ¹⁷ / ₃₂ " thru hole

RLS1000S	$^{51}/_{64}$ " C'bore x $^{9}/_{16}$ " deep, $^{17}/_{32}$ " thru hole
RLS1500S	$^{13}/_{16}$ " C'bore x $^{9}/_{16}$ " deep, $^{17}/_{32}$ " thru hole

POST TENSION/STRESSING JACK DIMENSIONS





Order Number	A (in.)	B (in.)	C (in.)	Weight (lbs.)
SJ2010	21	9	61/2	55
SJ2010	22	1013/64	7	76
SJ3010	22	1013/64	7	76
SJ3010P	22	1013/64	7	76
SJ2010DA	181/2	71/2	61/2	42
SJ3010DA	181/2	81/2	61/2	52

